




CAMRON / BENTON BABYKLEIDERSCHRANK 2T3L







1540 mm

2092 mm


























602 mm





Ø8






CAMRON / BENTON BABYKLEIDERSCHRANK 2T3L


B1 f 7 x 50 mm x16 	C2 x44 	D10 4 x 16 mm x16 	
D21 5 x 13 mm x2 	D5 3.5 x 16 mm x4 	D30 EURO 6.3 x 13 mm x8 	
D31 6.3 x 13 mm x24 	Q3 x20 	O0 x4 	
P0 x2 	M0 x8 	C10 6.3 x 20 mm x8 	
J3 x8 	J10 x8 	E0 5 x 50 mm x2 8 x 50 mm  	
K x1 4mm  	U2 x8 	N14 x3  L-450mm	
D16 4.2 x 28 mm x10 	L24 x5 	C0 x30 	
B0 x4 	S0 L-504mm x2  0		






CAMRON / BENTON BABYKLEIDERSCHRANK 2T3L





1	2032	565	16	x1	1/7
2	2032	565	16	x1	1/7
3	2032	565	16	x1	2/7
4	2032	565	16	x1	2/7
5	820	350	16	x1	4/7
6	820	350	16	x1	4/7
7	1540	602	40	x1	5/7
8	1540	602	40	x1	5/7
9	422	565	16	x1	4/7
10	422	545	16	x2	4/7
11	511	545	16	x5	3/7
12	450	180	16	x3	3/7
13	450	180	16	x3	3/7
14	288	177	16	x3	4/7
15	322	238	16	x3	4/7
16	2000	532	25	x1	6/7
17	2000	436	25	x1	7/7
18	2000	532	25	x1	6/7
19	444	298	2.8	x3	2/7
20	2042	521	2.8	x2	1/7
21	432	1206	2.8	x1	7/7
22	432	830	2.8	x1	7/7
S0					3/7
					4/6





1 ▶


<p>J3</p>  <p>x8</p>	<p>Q3</p>  <p>x10</p>	<p>O0</p>  <p>x2</p>
---	--	---

<p>D5</p> <p>3.5 x 16 mm</p> <p>x2</p> 
--







2 ▶

<p>Q3</p>  <p>x10</p>	<p>C10 6.3 x 20 mm x4</p> 
--	---







3▶

(C10) 6.3 x 20 mm 	x4	(O0) 	x2	(D5) 3.5 x 16 mm 	x2
--	-----------	--	-----------	---	-----------







4 ▶

(D31) 6,3 x 13 mm  x12	(N14)  L-450mm x3
--	--





5 ▶



(D31) 6,3 x 13 mm  x12	(N14)  L-450mm x3
--	--





6 ▶





7 ▶




8 ▶







9 ▶







10 ▶




<p>M0</p>  <p>x2</p>	<p>D30 EURO 6,3 x 13 mm x2</p> 
---	--




12▶










14▶




15▶



B1	f 7 x 50 mm	x4	K	x1
				
			4mm	







<p>M0</p>  <p>x2</p>	<p>D30 EURO 6,3 x 13 mm x2</p> 
---	--



17▶▶

<p>M0</p>  <p>x2</p>	<p>D30 EURO 6,3 x 13 mm x2</p> 
---	--





19 ▶

E0 5 x 50 mm **x2**
8 x 50 mm

X=10mm
Ø8
X=10

Warning diagrams showing correct and incorrect installation methods for screws and shelves.













Diagram showing the correct and incorrect way to install a shelf.




21 ▶








23▶





24▶







25▶




26 ▶



27 ▶



D16	4,2 x 28 mm	x4	L24		x2
